







washing machine table assembly instruction





A x2  508x190 H x1  425x505


B x2  480x172


C x2  445x172


I x1  617x554


D x2  480x172

J x6  508x46

E x2  475x455


K x4  M6x20


L x24  M5x16

F x1  525x494

M x16 

N x16 

G x1  525x494

O x2 


P x4  M4x18

step1


A x1 B x1

C x1 D x1

M x8 N x8




step2



X2

step3


A x1 E x1
O x1 P x2



X2

step4


F x1
G x1



step5

J x6


L x24




step6

I x1


K x4





step7




step8



step9
H x1





LET OP – BELANGRIJK

Zowel de verhoger als de wasmachine/droger moet waterpas afgesteld zijn. Zodra de wasmachine/droger waterpas staat deze pas plaatsen op de waterpas ingestelde verhoger.

WARNING- IMPORTANT

Both the washing machine and the pedestal must be leveled, before putting your washing machine on top of the pedestal.